

ZRTS GSG 1911-22 Thread Adapter Instructions

Thank you for purchasing our GSG 1911-22 thread adapter. Please read the following carefully to ensure proper fitment on your pistol.

***** **WARNING** *****

Failure to follow installation and maintenance instructions detailed in these instructions can result in potential for serious injury to the user and damage to the weapon. Firearm thread adapters are user attached firearm muzzle devices, and as such are subject to improper attachment unless the proper procedures outlined in these instructions are followed.

- 1.) Remove magazine and ensure that the firearm is unloaded.
- 2.) Remove threaded cap on GSG 1911-22 Barrel
- 3.) Thread the thread adapter on to barrel until tight using the GSG provided wrench.
- 4.) Ensure the back of the thread protector does not touch the barrel bushing or slide.

ZR Tactical Solutions, LLC is not responsible for any damage done to your weapon while installing or removing the device. ZRTS is also not responsible for any misuse of the device, any activity performed with device, or any crime or injury associated with use thereof. By installing the product, the user agrees to this statement. This product is potentially dangerous, and as such it is the user's responsibility to understand and implement its proper use. If you do not understand the instructions in this manual, please contact the manufacturer for further clarification.

